

# Täckfilm Blå för textila golv

**GOLVSKYDD**

Läggningsråd

Det är användarens ansvar att kontrollera lämpligheten för användning av denna produkt på avsett golv. Detta är på grund av att det finns så många olika sorters textilgolv och faktorer som kan påverka resultatet.

Täckfilmen applicerades  
**DATUM**

## Viktiga punkter

- Använd endast på textila golv.
- Rekommenderas inte på ull- och naturmattor och Flotex.
- Fler regelbundna kontroller bör göras vid användning på vissa mattor med skuren lugg eller flatvävd struktur. Kan fästa något hårdare på dessa.
- Appliceringstid: Upp till 45 dagar.
- Rumstemperatur, gångtrafik, luft- och golvfuktighet, solljus och längre appliceringstid än rekommenderat kan påverka resultatet.
- Använd täckfilmen inom 12 månader efter tillverkningsdatum (se etikett på förpackningen)  
Tiden förkortas om produkten förvaras eller hanteras felaktigt.



## Före appliceringen

- Förvara täckfilmen i en torr miljö, utan överdriven kyla/värme eller fukt. Rekommenderad temperatur vid förvaring är mellan 10-25 grader Celsius.
  - Stäng av eventuell golvvärme.
  - Applicera aldrig täckfilmen på en fuktig eller nytvättad matta.
  - För att undvika reaktion skall eventuellt golvlim under textilgolvet härdas innan täckfilmen appliceras. Vid tejlím/fixeringslim behövs ingen väntetid i normala fall. Kolla med respektive limtillverkare för mer info om torktider.
1. Kontrollera så att fukthalten i undergolvet och luften ligger inom hus AMA-11 krav för golvbeläggningar.
  2. Se till så att hela golvytan är dammfri och torr för bättre vidhäftning.

## Under appliceringen

1. Testa täckfilmen på en mindre oviktig yta först. Observera eventuella problem.
2. Täck hela golvytan lite omlott för optimalt skydd.  
Vi rekommenderar att använda Täckfilm Skarvrulle Blå för att täcka ända upp mot väggen/sockeln.

## Efter appliceringen

1. För att undvika luftbubblor eller andra ojämnheter rekommenderar vi att rolla med IMEX Applikator tvärs över våderna.
2. Kontrollera täckfilmen regelbundet. Observera eventuella problem.
3. För bästa kontroll, fyll i appliceringsdatum i rutan ovan och lämna kvar dokumentet på plats. Tips: Kläm dokumentet mellan en av täckfilmens överlapp.

## Avtäckning

1. Ta upp täckfilmen försiktigt.
2. Undvik onödig trafik på golvet minst 1 timme efter avtäckningen.
3. Täckfilmen skall inte återanvändas. Kassera miljövänligt. Avfallskod: 170203 Plast.

I händelse av att täckfilmen har lämnat limrester på mattan pga. onormala förhållanden, kontakta en proffsig mattvätt, typ Ångtvättbilen.

Detaljer i dokumentet kan ändras utan notifiering. Besök vår hemsida för de senaste läggningsråden. Rev.231227

# Carpet Film Blue

**GOLVSKYDD**

Recommendations

It is the user's responsibility to check the suitability of using this product on the intended floor. This is because there are so many different types of carpets and factors that can affect the result.

Application date of the  
carpet film

**DATE**

## Important points

- Use only on carpet / textile floors.
- Not recommended on wool- and natural carpets or Flotex.
- More regular checks should be made when using on certain cut pile and flat-woven carpets.
- Application duration: Up to 45 days.
- Room temperature, traffic, air and floor humidity, sunlight and longer application time than recommended may affect the result.
- Use the carpet film within 12 months of the date of manufacture. (see label on the package)  
The time is shortened if the product is stored or handled incorrectly.



## Before

- Store the carpet film in a dry environment, without excessive cold/heat or moisture. The recommended temperature for storage is between 10-25 degrees Celcius.
  - Turn off any underfloor heating.
  - Never install on a damp or freshly washed carpet.
  - To avoid glue reaction, any floor adhesive must harden before the film is applied to the carpet. If the carpet is installed with a tackifier, no waiting time is normally required. Contact adhesive manufacturer for more information.
1. Check that the moisture content of the subfloor and air is within house AMA-11 requirements for floor coverings.
  2. Make sure the floor is dust-free for better adhesion.

## During

1. Try the carpet film on a smaller unimportant area first. Observe closely for potential problems.
2. Cover the entire floor area for a better result.  
We recommend using our Täckfilm Skarvrulle Blå to cover right up to the wall.

## After

1. We recommend rerolling the applied film one or a few extra times using the IMEX Applikator in different directions.
2. Make regular checks and observe closely for potential problems.
3. For best control, fill in the application date in the box above and leave the document on site. Tip: Trap it between the overlaps of the carpet film.

## Removal

1. Remove the carpet film carefully.
2. Avoid unnecessary traffic on the floor minimum 1 hour after removing the carpet film.
3. Do not reuse the carpet film. Discard environmentally friendly. Waste code: 170203 Plastics.

In the event that the carpet film has left adhesive residues on the carpet due to abnormal conditions, contact a professional carpet cleaner such as Ångtvättbilen.

Details in this document may change without notification. Please visit our website for the latest recommendations.