

# Täckfilm Grön för hårda golv

**GOLVSKYDD**

Läggningsråd

Det är användarens ansvar att kontrollera lämpligheten för användning av denna produkt på avsett golv. Detta är på grund av att det finns så många olika sorters golv och faktorer som kan påverka resultatet.

Täckfilmen applicerades  
**DATUM**

## Viktiga punkter

- Använd endast på hårda golv
- Använd inte längre än några dagar på nylagda trägolv
- Applicera med IMEX Applikator (på stora ytor) för bästa resultat
- Appliceringstid: Max 45 dagar.
- Använd inte på textila golv, använd IMEX Täckfilm Blå istället
- Stäng av eventuell golvvärme för bästa resultat
- Rumstemperatur, gångtrafik, luft- och golvfuktighet, solljus och längre appliceringstid än rekommenderat kan påverka resultatet.
- Använd täckfilmen inom 12 månader efter tillverkningsdatum (se etikett på förpackningen) Tiden förkortas om produkten förvaras eller hanteras felaktigt



## Föreläggning

- Förvara täckfilmen i en torr miljö, utan överdriven kyla/värme eller fukt. Rekommenderad temperatur vid förvaring är mellan 10-25 grader Celsius.
- Applicera aldrig täckfilmen på en fuktig eller nytvättat golv.
  1. Kontrollera så att fukthalten i undergolvet och luften ligger inom hus AMA-11 krav för golvbeläggningar.
  2. Se till så att hela golvytan är dammfri och torr för bättre vidhäftning.

## Underläggning

1. Testa täckfilmen på en mindre oviktig yta. Observera eventuella problem.
2. Täck hela golvytan lite omlott.

## Efterläggning

1. För att undvika luftbubblor eller andra ojämnheter rekommenderar vi att rolla med IMEX Applikator tvärs över våderna.
2. Kontrollera täckfilmen regelbundet. Observera eventuella problem.
3. För bästa kontroll, fyll i appliceringsdatum i rutan ovan och lämna kvar dokumentet på plats. Tips: Kläm dokumentet mellan en av täckfilmens överlapp.

## Avtäckning

1. Ta upp täckfilmen försiktigt för bästa resultat.
2. Undvik onödig trafik på golvet minst 1 timme efter avtäckningen.
3. Täckfilmen skall inte återanvändas. Kassera miljövänligt. Avfallskod: 170203 Plast.

I händelse av att täckfilmen har lämnat limrester på mattan pga. onormala förhållanden, kontakta en proffsig mattvätt, typ Ängtvättbilen.

Detaljer i dokumentet kan ändras utan notifiering. Besök vår hemsida för de senaste läggningsråden. Rev.231227

# Protection film Green

**GOLVSKYDD**

Recommendations

It is the user's responsibility to check the suitability of using this product on the intended floor. This is because there are so many different types of floors and factors that can affect the result.

## Important points

- Use only on hard floors
- Application time only a few days on newly laid wood floors
- Apply with IMEX Applicator (on large surfaces) for best results
- Application time: Max 45 days.
- Do not use on textile floor, use Carpet film Blue instead
- Turn off any underfloor heating for best results
- Room temperature, traffic, air and floor humidity, sunlight and longer application time than recommended may affect the result
- Use the carpet film within 12 months of the date of manufacture. (see label on the package) The time is shortened if the product is stored or handled incorrectly.

Application date of the  
carpet film

**DATE**



## Before

- Store the carpet film in a dry environment, without excessive cold/heat or moisture. The recommended temperature for storage is between 10-25 degrees Celcius.
  - Never install on a damp or freshly washed floor. The reason is possible risk for chemical reaction.
1. Check that the moisture content of the subfloor and air is within house AMA-11 requirements for floor coverings.
  2. Make sure the floor is dust-free for better adhesion.

## During

1. Try the carpetfilm on a smaller unimportant area. Observe closely for potential problems.
2. Cover the entire floor area overlapping.

## After

1. We recommend rerolling the applied film one or a few extra times using the IMEX Applikator in different directions.
2. Make regular checks and observe closely for potential problems.
3. For best control, fill in the application date in the box above and leave the document on site. Tip: Trap it between the overlaps of the carpet film.

## Removal

9. Carefully remove the cover film for best results.
10. Avoid unnecessary traffic on the floor minimum 1 hour after removing the cover film.
11. Do not reuse the cover film. Discard environmentally friendly. Waste code: 170203 Plastics.

In the event that the carpet film has left adhesive residues on the carpet due to abnormal conditions, contact a professional carpet cleaner such as Ångtvättbilen.

Details in this document may change without notification. Please visit our website for the latest recommendations.